

## How to Assemble a flat packed Warehouse Step.



1. With the wheels of the back section at the bottom, fit to front section at point A. Secure with nuts and bolts provided.
2. Fit H-shape brace with (cross brace on the top side) to the base of the ladder. Secure with nuts and bolts provided.
3. Slide platform into position. Secure with nuts and bolts provided.
4. Align the back leg K-straps at the bottom of the back section with the pre drilled holes on the H-brace. Secure with nuts and bolts provided.
5. Where required (WS8 and above) fit cross brace to back leg at predrilled position. Secure with nuts and bolts provided.
6. Ensure all connections are secure, with no movement being present to the joints. Ensure ladder base is level and does not rock when placed squarely on the ground.